






Magnetic Featherboard


Sometimes clamping a featherboard to the table saw is more trouble than it's worth. The cast ribs underneath the saw table always seem to get in the way of the clamps. And when I need to move the featherboard just a hair, it's a pain to reposition the clamps.





The unique feature on these bases is a switch that lets you "turn" the magnetic field on or off. Once the featherboard is in position, you simply flip on both switches to secure it to the saw table. To reposition (or remove) the featherboard, just turn the switches off.

To make this work, a featherboard is attached to an L-shaped support, like you see in the drawing below. After cutting an angled notch to fit the featherboard, I rabbeted each end of the top to fit the magnetic bases. A threaded hole in the top of each base makes it easy to bolt them to the support.



Have a nice weekend,

Bryan Nelson Online Editor, ShopNotes



Join Woodsmith for a tour to the very heart of traditional American woodworking! Read more...





More Tips & Techniques

Index of Tips by Email ▶ 101 Tips & Techniques

Your Email Account

- Update Your Email Address
- Unsubscribe
- Privacy Policy

Subscriber Links

- Email This Page To A Friend
- Contact Us

