


JDP-17, Instruction for changing the power supply



文件編號 :		製表日期 :	2023.01.05	修訂日期 :	2023.01.05	版次 :	V1	頁次 :	1	承認 :	
Description :	The process for changing the power supply.									審核 :	
										作者 :	廖庭億



Step 1 Remove the panel by loosen the screws.

Step 2 Remove the existing power supply and change to use the new power supply.

Step 3 Connect the brown wire and the white wire (L) together with the terminal, and also the blue wire and the black wire (N)



Step 4 Connect all the connector.

Step 5 After tidy the wire up, put the panel back and fasten the screws.