LOOSEN THESE BOLTS
TO RESET INSIDE
CLEARANCE DIMENSION
SLIDE
BAR
LOCK
ADJUSTING
NUT
INSIDE CLEARANCE DIMENSION
RAIL WIDTH + 1/16"

5

2
1
3
CABLE
CABLE MUST
CROSS HERE
PULLEY
4
5
6
CABLE
BLOCK

4